



# MAINTENANCE SCHEDULE

## 2003-2004 DISCOVERY Series II

Owner's Name: \_\_\_\_\_

Date: \_\_\_\_\_ Mileage \_\_\_\_\_ RO#: \_\_\_\_\_

MAINTENANCE INTERVAL	TIME (Months)	6	12	18	24	30	36	42	48
	MILES (Thousands)	7.5*	15*	22.5*	30*	37.5*	45*	52.5	60
	KILOMETERS (Thousands)	12	24	36	48	60	72	84	96

\*2004 Discovery vehicles registered in the U.S. and PR include the first six scheduled maintenance services at not charge when performed at a LR Retailer

### 1 VEHICLE INTERIOR

1.1 Check parking brake (Adjust if necessary)		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
1.2 Check seat belts		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>

### 2 VEHICLE EXTERIOR

2.1 Add 16 oz Land Rover Fuel Conditioner (LRN5010)	<input type="checkbox"/>								
2.2 Inspect wiper blades	<input type="checkbox"/>								
2.3 Lubricate door locks, check straps, all-door hinges, hood latch and safety catch, fuel door hinges		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
2.4 Replace Alarm handset batteries					<input type="checkbox"/>				<input type="checkbox"/>

### 3 UNDER HOOD

3.1 Inspect coolant hoses		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3.2 Inspect radiator and AC condenser		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3.3 Check power steering fluid level/ACE fluid level		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3.4 Inspect serpentine drive belt		<input type="checkbox"/>			<input type="checkbox"/>				<input type="checkbox"/>
3.5 Clean and service battery and terminals		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3.6 Check brake fluid level		<input type="checkbox"/>					<input type="checkbox"/>		
3.7 Change brake fluid					<input type="checkbox"/>				<input type="checkbox"/>
3.8 ❖ Replace air-cleaner element					<input type="checkbox"/>				<input type="checkbox"/>
3.9 Change engine coolant					<input type="checkbox"/>				<input type="checkbox"/>
3.10❖ Replace spark plugs									<input type="checkbox"/>
3.11Replace serpentine drive belt							<input type="checkbox"/>		

### 4 UNDER VEHICLE

4.1 Inspect tire pressures, condition and tread depth	<input type="checkbox"/>								
4.2 Lubricate wheel centers and install road wheels on same axle opposite side unless directional tires are fitted	<input type="checkbox"/>								
4.3 Perform body corrosion warranty inspection	<input type="checkbox"/>								
4.4 Inspect brake pads, calipers and discs	<input type="checkbox"/>								
4.5 ❖ Change engine oil and replace filter	<input type="checkbox"/>								
4.6 Inspect exhaust system and heat shields		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
4.7 Inspect brake lines		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
4.8 Inspect for free play in propeller shaft universal/sliding joints and lubricate sliding joints		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
4.9 Inspect steering rods, joints and dust covers		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
4.10Inspect shock absorbers		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
4.11Check trailer hitch attachment bolts for tightness	<input type="checkbox"/>				<input type="checkbox"/>			<input type="checkbox"/>	
4.12Inspect suspension links and mountings		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
4.13Inspect wheel speed sensor and height sensor wiring		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
4.14Inspect fuel and hydraulic lines		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
4.15Change transfer gearbox oil					<input type="checkbox"/>				<input type="checkbox"/>
4.16Check front and rear axle oil level					<input type="checkbox"/>				<input type="checkbox"/>
4.17Change transmission fluid					<input type="checkbox"/>				<input type="checkbox"/>
4.18Replace transmission fluid filter (One-time only)					<input type="checkbox"/>				
4.19Inspect engine and transmission mounts							<input type="checkbox"/>		
4.20Check steering box for freeplay									
4.21Change front and rear axle oil	<input type="checkbox"/>								
4.22Service ACE filter (If equipped)									
4.23Service SLS filter (If equipped)									<input type="checkbox"/>
4.24Perform road test and endorse Passport to Service	<input type="checkbox"/>								

### ❖ REQUIRED EMISSION MAINTENANCE

**SUPPLEMENTARY RESTRAINT SYSTEM (SRS):** The AIR BAGS in the SRS must be replaced EVERY TEN YEARS.  
The SEAT BELT PRETENSIONERS must be replaced EVERY 15 YEARS

### NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.